PART NO. 25435

Instruction Sheet TOYOTA REPLACEMENT CAMBER/CASTER CAM KIT

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

- 1. Before beginning alignment, inspect for loose or worn parts and replace as necessary, check tire pressure, and look for odd tire wear.
- 2. Raise front of vehicle and properly support it by frame.
- 3. Install cams on bolts per Figure 1.
- 4. Install plastic sleeve on forward (larger) bolt.

Note: Cams may be stamped with all eight digits as indicated in Figure 1. or only with the last four digits of the indicated cam number.

5. One at a time, remove original cam assemblies from lower control arm and replace them with the SPC assembly, installing new assemblies as shown (Figure 1).

SPC tool 40915 may help with removal of OEM cams. However, if tubes are solidly seized in bushings, you may not be able to remove them. To achieve camber/ caster change, you may need to replace upper control arms with SPC's Adjustable Upper Arms - check Sourcebook™ or www.specprod.com for correct applications.


- 6. Install appropriate remaining cam and nut on each bolt and loosely tighten.
- 7. Lower vehicle, jounce suspension, and use cams to adjust alignment to desired

settings by turning the bolt.

and tighten nut to 150 ft-lb to lock settings. Always check for proper clearance between suspension components and other

the vehicle. 9. Adjust toe and road test vehicle.

components of





Specialty Products Company

P.O. Box 923 • Longmont, CO 80502 • (303) 772-2103 • Fax: (303) 772-1918 www.specprod.com • www.spcperformance.com • Email:info@specprod.com Toll Free Technical Hot Line: 1-800-525-6505